

International Power Configuration

The table below represents international power configurations for Winston CVap® products. Please contact the factory for additional information if needed.

		380V/3 WYE		400V/3 WYE			
	208V		220V		230V		240V
CHV-04UV	Yes	CHV-04UV	Yes	CHV-04UV	Yes	CHV-04UV	Yes
CHV-04HP	Yes	CHV-04HP	Yes	CHV-04HP	Yes	CHV-04HP	Yes
CHV-05UV	Yes/3ph	CHV-05UV	Yes	CHV-05UV	Yes	CHV-05UV	Yes
CHV-14UV	Yes/3ph	CHV-14UV	No	CHV-14UV	No	CHV-14UV	Yes
HOV-04HP	No	HOV-04HP	No	HOV-04HP	No	HOV-04HP	No
HOV-04UV	Yes	HOV-04UV	Yes	HOV-04UV	Yes	HOV-04UV	Yes
HOV-05UV	Yes	HOV-05UV	Yes	HOV-05UV	Yes	HOV-05UV	Yes
HOV-05SP	Yes	HOV-05SP	Yes	HOV-05SP	Yes	HOV-05SP	Yes
HOV-14SP	Yes	HOV-14SP	Yes	HOV-14SP	Yes	HOV-14SP	Yes
HOV-14UV	Yes	HOV-14UV	Yes	HOV-14UV	Yes	HOV-14UV	Yes
RTV-04UV	Yes/3ph	RTV-04UV	No	RTV-04UV	Yes	RTV-04UV	Yes
RTV-05UV	Yes/3ph	RTV-05UV	No	RTV-05UV	Yes	RTV-05UV	Yes
RTV-14UV	Only 3ph	RTV-14UV	No	RTV-14UV	No	RTV-14UV	Only 3ph