

AC1006 Top Extension and Fan Cover INSTRUCTION MANUAL

TOOL(S) NEEDED

- Phillip's head screwdriver

1. Insert the eight provided grommets into the the square holes on the extension front and back pieces. (Fig.1-2)




Fig.1




Fig.2

2. Using a Phillips screwdriver, attach the two sides to the front and back. Ensure the top side is flush. (Fig.3-4)



Fig.3




Fig.4

3. Using a Phillips screwdriver, remove the two top screws on the side panels towards the back. (Fig.5-6)



Fig.5



Fig.6

4. Place fan cover over on top back and secure with the screws that were removed from the sides. (Fig.7-8)



Fig.7



Fig.8

5. Using a Phillip's head screwdriver, remove six screws that secure unit top, and place the top extension onto the unit top. (Fig.9-11)



Fig.9



Fig.10



Fig.11

6. Ensure that the extension is aligned to top screw holes. Replace unit top screws. (Fig.12-13)



Fig.12




Fig.13