

PS3173 Top Extension 8.5 UV INSTRUCTION MANUAL

TOOL(S) NEEDED

- Phillip's head screwdriver

1. Using six provided screws and a Phillip's head screwdriver, connect the two side panels to front panel (**Figure 1**).
2. Using six provided screws and a Phillip's head screwdriver, connect back to top extension assembly (**Figures 2 & 3**).




Figure 1



Figure 2



Figure 3

3. Using a Phillip's head screwdriver, remove six screws that secure unit top (**Figures 4 & 5**).
4. Carefully place top extension onto the top of unit. Ensure that all sides are flush (**Figure 6**).



Figure 4



Figure 5



Figure 6

Buy Winston service parts online!
Factory direct at www.winstonparts.com

5. Align the screw slots on the top extension with the unit top screw slots. Using a Phillip's head screwdriver, secure the top extension to the unit using the six screws that held unit top (**Figures 7 & 8**).



Figure 7



Figure 8

Buy Winston service parts online!
Factory direct at www.winstonparts.com